


This guide will address common tasks for getting started with your classroom's Smart Board:

1. Turning on the Smart Board.
2. Using the Smart Board's Ink Layer.
3. The Smart Board buttons.

Detailed Instructions

1 Turning on the Smart Board.

You can verify that your computer is connected to the Smart Board by looking for the blue disk icon  at the bottom right-hand corner of your screen. You may immediately begin using the Smart Board by touching the board to use your finger as the mouse. If you see a red X on top of the blue disk icon, then the Smart Board is not connecting to your computer and you should contact the **Helpdesk** immediately at **817-531-4428**.

2 Using the Smart Board's Ink Layer.

- To activate the **Ink Layer** pick up a pen and start writing on the Smart Board.
- If you have a large area to erase on Smart Board, draw a big circle around the area with the eraser, then tap in the center of the circle.
- Press the **camera icon** in the upper right hand corner of the **Ink Layer** to save the current Ink Layer to a new notebook (Fig. 1).
- Press the **red X** to close the **Ink Layer** and return to mouse control.
- To view your saved **Ink Layers**, find the minimized **Notebook** program on your taskbar



Fig. 1



and click it to restore the program and save the slides.

- To save the slides in PowerPoint format go to the **File** menu, select **Export ► PowerPoint**, type a name for the file and click **Save**.
- While using PowerPoint, you can double-tap the screen with your finger to move to the next slide.

3 The Smart Board buttons.

1. The **keyboard** button: a keyboard pops up on the screen.
2. The **mouse** button: the next touch on the Smart Board will register as a right mouse click.
3. The **help** button: a dialog box appears with links to align the Smart Board, help and technical resources from Smart Technologies



Fig. 2

If the smart board does not register your finger or markers correctly try aligning the screen again:

1. Click the **Help** button on the Smart Board and choose **Align/ORIENT the Smart Board**.
2. Touch the middle of the 9 targets as each appears on the screen (Fig. 3).



Fig. 3